RS Venture Unrigging Checklist v2

Attach mooring pendant carabiner to dyneema loop at bow

Tightly Furl Jib, Cleat Jib Furling Line and Jib Sheets

Douse main

Attach main halyard to port side of boom end and trim halyard till boom is level

Roll Main from middle batten and tie to boom with sail ties with slippery ½ hitches. Leave tack slug reefing lines and outhaul attached.

Cover main

Stuff spinnaker in chute. Cover spinnaker chute. Lead shockcord around forestay and to foredeck padeye

Tip Rudders up

Attach elastic rudder retainer to tiller ends

Coil all lines at mast and hang with cunningham

Trim and cleat mainsheet so the boom doesn't swing back and forth. Flake mainsheet and hang from the sailcover clip.

Wash deck and cockpit with soap and water

Does anything need repair? Complete Maintenance form at RentonSailing.org

Sign into log book